



Fitting Instructions for RAD0089BK/TI Radiator Guard Honda VFR1200 2010-



In This Kit There Should Be
1x Radiator Guard
1 x Cable/Zip Ties
2x 100mm Lengths of Foam

- To fit the radiator guard you will need to remove the front radiator surround and both side panels.
- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator. The cable tie goes through the slots at the top of the radiator guard and around the mounting brackets of the radiator as shown above right. At the bottom bolt the radiator guard to the original mountings bracket using the original bolts as shown above left. When the guard is in position tighten the cable tie.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



FRANCE

Instructions de montage de la protection de radiateur RAD0089BK/TI Honda VFR1200 2010-

Pièces nécessaire dans le kit:

1x protection de radiateur

1 x collier de serrage

2x longueurs de 100mm de mousse

- Pour fixer la protection de radiateur, vous devrez enlever l'entourage du radiateur et les 2 caches latéraux.
- Pour fixer la protection de radiateur sur la moto, couper des morceaux de mousse (longueur 10mm) et les coller sur l'arrière de la protection de radiateur. De manière à ce qu'ils se positionnent entre la protection et le radiateur. Le collier de serrage se positionnera sur la fixation supérieure de la protection de radiateur (voir photo de droite) et devra entourer la patte de fixation de radiateur. Pour la fixation basse, utilisez la vis de fixation d'origine (voir photo de gauche). Une fois la protection en place, serrer le collier fermement.

Montageanleitung für den RAD0089BK/TI Kühlerschutz Honda VFR1200 2010-



Dieser Kit enthält:

1x Kühlerschutz

1 x Kabelbinder

2x 100mm Schaumstoffstreifen

- Entfernen Sie zuerst die vordere Verkleidung um den Kühler und beide Seitenverkleidungen. Um den Kühlerschutz am Motorrad zu montieren, schneiden Sie zuerst die mitgelieferten Schaumstoffstreifen in 10 mm breiten Streifen und kleben Sie diese auf der Rückseite des Kühlerschutzrahmens, so dass sie zwischen dem Kühlerschutz und dem Kühler angebracht sind. Führen Sie den Kabelbinder durch die zwei Schlitze oben auf dem Kühlerschutz, dann um die oberen Kühlerschutzhälter, wie rechts abgebildet. Verwenden Sie die Originalschraube, um den Kühlerschutz unten am Originalhalter zu befestigen (siehe Abbildung oben links). Wenn der Kühlerschutz in der richtigen Position ist, ziehen Sie die Kabelbinder fest.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com